ROKR

MARBLE RUN

LG412 MARBLE SPACEPORT



ASSEMBLY INSTRUCTION

WARNING!

- Keep small parts and packaging materials away from children.
- Do not use the product if any parts are missing or broken, and do not modify the product in any way.
- Do not use the product if the instructions are missing or illegible.
- Remove the product from the packaging and check for any sharp edges or burrs. If any are present, sand them down or remove them with a file before use.
- Remove any plastic and paper protection, if any, and clean all components with a dry cloth before assembling the product.
- Do not use the product near heat sources or in direct sunlight.
- Do not use the product in the presence of children under the age of 3 years old.
- The product is suitable for children from the age of 14 years old.
- Do not use the product in the presence of children without adult supervision.
- Do not use the product in the presence of children who are not able to follow the safety instructions and who are not able to use the product in a safe way.
- Do not use the product in the presence of children who are not able to understand the hazards associated with the use of the product.
- Do not use the product in the presence of children who are not able to understand the consequences of improper use of the product.
- The product is intended for indoor use only.
- Do not use the product in the presence of children who are not able to understand the consequences of improper use of the product.
- Do not use the product in the presence of children who are not able to understand the consequences of improper use of the product.

CUSTOMER SERVICE

Email: Support_en@rokrstudio.com, Support_de@rokrstudio.com, Support_fr@rokrstudio.com, Support_es@rokrstudio.com

ATTENTION

- Please read the instructions carefully before assembling to avoid unnecessary damage and loss.
- Please carefully check the parts and packaging before assembling and contact us in time if there is any damage or missing parts.
- Some small parts are packaged in continuous sections. Separate gently along indentations.
- Some parts are packaged in bags to prevent damage during transportation. Please remove them before assembling.
- Due to manual measurement, there may be a slight error in the dimensions of the parts, which is a normal phenomenon and does not affect the overall use.
- Due to a slight difference between actual and CAD models, the accessories in instructions, please refer to the actual product.

ROKR STANDARD

- Tolerance: ±0.3mm (Tolerance for accuracy of lightness and thickness ±0.1mm, tolerance for other lengths ±0.3mm).
- Assembly: Suitable for most people, but some steps require more patience and attention to ensure a smooth assembly process.

Recommended tools: Tweezers, Pliers, Screwdriver, Rubber mallet, Scissors, Cutter, Ruler, Tape measure, Sandpaper, Glue, Lubricant, Cotton swab, Cloth, Magnifying glass, Flashlight, Pen, Paper, Tape, Storage box, Storage bag, Sorting tray, Magnet, Magnet tool, Magnetic pad, Magnetic ball, Magnetic rod, Magnetic tweezers, Magnetic screwdriver, Magnetic pliers, Magnetic hammer, Magnetic sorting tray, Magnetic storage box, Magnetic storage bag


Hand rotation mode
Refer to instructions to ensure the model is correctly placed. Ensure the shaft is placed parallel to switch to the cranks mode.
Instructions:
1. Place the handle in the drive position.
2. Rotate the handle clockwise.
3. Observe the model's movement in cycle motion with the running mechanisms.
FAQs:
1. Pass fitting mechanism doesn't work smoothly, check the seating slot in Step 6.
2. Ensure the shaft is correctly placed in the mechanisms. A tick sound, with no loud or jerky mechanisms, indicates correct placement. Adjust if necessary.
Unsure shaft sensors and flash with steel shaft sticky.
Disconnected state
The assembly disconnects from the electric module.
Connected state
The assembly connects to the electric module.
Instructions:
1. Ensure the battery is fully charged.
2. Place O-ring (red ball).
3. Place the assembly onto the Type C port for the power connection.
4. The assembly connects to the electric module automatically on the mechanism side.
5. Upon completion of the hand rotation mode, then disconnect the power, remove the battery and stow the assembly in storage.
6. The model can connect with Rubik Night City with the assembly and light.
SCAN TO DOWNLOAD
ROKR
Cycle Into Endless Excitement
45.5.UG01.100